

SUPORTI TEL./PDA

| | |
|--|--------|
| Passive HTC P3600/Trinity | 848715 |
| Passive Apple iPod Nano Video | 840760 |
| Passive Creative ZENVision M30GB | 848668 |
| Passive holder-Siemens | 848538 |
| Passive iPhone 4GB | 875168 |
| Holder HP iPAQ 2210/2250- cu connector | 848574 |
| Passive iPod | 848636 |
| Sony PSP-1001k | 848683 |
| Fujitsu-Siemens Pocket Loox 700 | 847608 |
| Passive Handspring Treo 600/650 | 848590 |
| Holder Mitac Mio 168/336 -cu conector | 849606 |
| Passive HTC TyTN | 848691 |
| Passive Mitac Mio A701 | 848682 |
| Passive Garmin iQue | 848581 |
| Passive HP iPAQ 19xx | 848560 |
| Passive Apple iPod Mini | 848603 |
| Passive Fujitsu-Siemens Pocket Loox 700-series | 848608 |
| Passive HP 610c Business Navigator | 848776 |
| Passive Blackberry 6510 | 848557 |
| Passive Qtek 9100 | 848655 |
| Passive iPAQ hx4700-pt.cablu | 847621 |
| Holder Ipaq 36xx/37xx EXP for Connector | 848528 |
| Passive T-mobile MDA/Qtek 2020 | 848582 |
| Passive Qtek8020/SPV C600 | 848975 |
| Active iPhone 4GB | 915168 |
| Passive Toshiba E330/E740-ptr. Conector | 848543 |
| Passive HTC Touch Pro | 848848 |
| Passive ETEN M700 Clodfish | 848733 |
| Passive Yakumo Alpha GPS | 848645 |
| Passive Toshiba 330,350,740,750 | 848553 |
| Passive Asus P535 | 848737 |
| Passive T-mobile Qtek 9090 | 848612 |
| Passive Qtek S100 | 848625 |
| Holder HP iPAQ 6500/6700 built in connector | 849639 |
| Passive HTC cruiser | 848773 |
| Passive Asus A620/A716 | 848587 |
| Holder for iphone 4 GB with cable attachment | 915219 |
| Nokia 7710- | 875011 |
| Nokia 6280 | 875068 |
| Nokia 6680/6681 | 875012 |
| Passive Qtek8020/SPV C600 | 848975 |
| N80 for Nokia handsfree cable | 905087 |
| N73 for Nokia handsfree cable | 905120 |
| Nokia 6260 | 848963 |
| Passive Sony Ericsson Z520i/Z300i | 875026 |
| N90 | 875039 |
| N70 for Nokia handsfree cable | 905044 |
| N80 | 875087 |
| N95/8GB | 875178 |
| Nokia 7650 | 841844 |
| Motorola SLVR | 875061 |
| Sony Ericsson K550i | 875144 |
| Nokia 6300 | 875131 |
| Nokia N78 | 875232 |
| Motorola RIZR Z3 | 875159 |
| E51 | 875180 |
| Nokia 6650 | 941910 |

| | |
|-----------------------------|--------|
| Nokia 8910 | 841886 |
| Nokia 8850 | 841772 |
| Nokia 6680/6681 | 870012 |
| Nokia 9210 | 841815 |
| Sony Ericsson P800 | 841857 |
| Nokia 8210 | 841767 |
| Passive SysOn Bluetooth GPS | 213097 |
| Nokia 6100 | 841866 |
| Sony Ericsson K700i | 841929 |
| Siemens C60 | 841920 |
| Nokia 3210/51/61/71 | 842699 |
| Siemens S65 | 841985 |
| Nokia 9300 | 841980 |
| Nokia 6280 | 870068 |
| Nokia 6131 | 870122 |
| N90 | 870039 |
| Nokia 7650 | 841844 |
| Nokia 7610 | 841930 |
| Nokia 3650 | 841867 |
| Motorola V3 | 841968 |
| E61 | 870098 |
| Nokia 7270/6170 | 841977 |
| Samsung D500 | 841989 |
| Nokia 7710- | 870011 |
| Passive Qtek 8010 SPV500 | 841959 |
| Sony Ericsson P900 | 841897 |
| Nokia 2100/6820 | 841872 |
| Sony Ericsson T610 | 841877 |
| N80 | 870087 |
| Nokia 6220/6230 | 841909 |
| N73 | 870120 |
| Samsung SGH-E700 | 841905 |
| E90 | 870165 |
| Samsung T809 | 870069 |
| Nokia 6600 | 841894 |
| Panasonic GD87 | 841855 |
| Sony Ericsson K600i/K608i | 870027 |
| Ericsson T68 | 841821 |
| Sony Ericsson M600i | 870089 |